

## En SETTING UP

### 1 - CONNECTING TELEPHONE

The plug at the end of the lead should be connected to the telephone socket.

*Voltages present on the telecommunication network are classified TNV-3 (Telecommunication Network Voltage) according to the EN60950 standard.*

### 2 - RINGER SETTING

A switch located on the right of the base allows to switch **OFF, LO** or **HI** the ringer.

### 3 - WALL MOUNTING

To wall-mount your telephone, slide out the clip turn around and slide back into the wall mounting position (located in the base unit, just below the ear piece). This will ensure that the handset stays firmly in position. Make 2 holes in the wall 80mm apart, insert the wall plugs and the wall mounting screws. The screws should protrude from wall by 10 mm. Place the phone onto the screw-heads and slide down to secure.

## USING THE TELEPHONE

### 1 - ANSWERING INCOMING CALLS

When an incoming call is received, the telephone will ring. To answer the call lift the handset and speak.

### 2 - MAKING A CALL

Lift the handset, await the dial tone and dial required number. Lift the handset, await the dial tone and dial required number. On completion of the call, carefully replace the handset in the cradle.

### 3 - LAST NUMBER REDIAL



Lift the handset, await the dial tone and press the  (**Redial**) button. The previously dialed number will be AUTOMATICALLY RE-DIALLED.

### 4 - R, \* & # BUTTONS:

These are used with the new services provided on digital

exchanges. For details please contact your network operator.

### 5 - MUTE BUTTON

If you wish to speak privately to someone else in the room (without your caller overhearing) press and hold the  (**Mute**) button. Your caller may still be heard during the MUTE operation. To resume normal conversation, release the  (**Mute**) button.

## GUARANTEE

From the moment your Geemarc product is purchased, Geemarc guarantee it for the period of two years. During this time, all repairs or replacements (at our discretion) are free of charge. Should you experience a problem then contact our helpline or visit our website at [www.geemarc.com](http://www.geemarc.com). The guarantee does not cover accidents, negligence or breakages to any parts. The product must not be tampered with or taken apart by anyone who is not an authorised Geemarc representative. The Geemarc guarantee in no way limits your legal rights.

**IMPORTANT: YOUR RECEIPT IS PART OF YOUR GUARANTEE AND MUST BE RETAINED AND PRODUCED IN THE EVENT OF A WARRANTY CLAIM**

**Please note: The guarantee applies to the United Kingdom only.**

**DECLARATION:** Geemarc Telecom SA here by declares that this product is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive 2014/53/UE and in particular article 3 section 1a, 1b and section 2. The telephone does not operate if the line current is lower than 18 mA.

*The declaration of conformity may be consulted at [www.geemarc.com](http://www.geemarc.com)*

**Telephone connection:** Voltages present on the telecommunication network are classified TNV-3 (Telecommunication Network Voltage) according to the EN60950 standard.

## RECYCLING DIRECTIVES



2

The WEEE (Waste Electrical and Electronic Equipment) has been put in place for the products in end of life are recycled in the best way.

When this product is out of order, please do not put it in your domestic waste bin. Please use one of the following disposal options:

- Remove the batteries and deposit them in an appropriate WEEE skip. Deposit the product in a appropriate WEEE skip.
- Or hand the old product to the retailer. If you purchase a new one, they should accept it.

Thus if you respect these instructions you ensure human health and environmental protection.



For product support and help visit our website at [www.geemarc.com](http://www.geemarc.com) telephone **01707 387602** or fax **01707 832529**

## Fr INSTALLATION

### 1 - RACCORDEMENTS

Branchez le connecteur téléphonique dans la prise téléphonique murale.

*Les tensions présentées sur ce réseau sont classées TRT-3 (Tension de Réseau de Télécommunication) au sens de la norme EN60950.*

### 2 - SONNERIE

Un commutateur situé à droite de la base permet de régler la sonnerie.

**HI:** sonnerie forte. **LO:** sonnerie faible. **OFF:** sonnerie désactivée..

### 3 - POSITION MURALE

Pour maintenir votre combiné en position verticale, retirez l'ergot situé sur la base (en dessous du bouton de raccroché), le tourner et le réinsérer. Percez 2 trous verticaux distants de 80 mm dans votre mur pour y insérer 2 chevilles avec leurs vis. Vous pouvez vous aider du gabarit de perçage. Laissez dépasser les vis de 10mm environ.

Faites glisser ensuite votre téléphone dans les têtes de vis.

3